

Date: Thursday, November 12, 2009

Number: TAB-09-014

To: Global Sales Channel

Notice: PC5108 jumpers defaulted for use with New PowerSeries panels

Effective November 6, 2009, DSC has begun transitioning the PC5108 Zone Expander modules to include new jumper default settings for use with the New PowerSeries control panels (PC1616/1832/1864 V4.X). During this transition period, orders may contain product with prior and/or new default settings.

Jumpers J1 – J3 will be configured for zones 9-16 to be assigned to the zone expander:

J1 - OFF

J2 – ON

J3 – ON

Previously, the jumpers were set for zones 17-24 for panels V3.X and higher.

NOTE: Jumper settings for J4 – J6 are not used when the PC5108 is used with a V3.X and higher control panel.